

Loading Your CD On-Hold Messaging Player



1. Make sure the CD Autoload System is powered ON.
2. The power button is on the back of the unit. Light should be solid green.
3. Lift the lid and insert the CD. The record light will flash red while the system is loading.
4. Load will take 5 to 7 minutes, please allow the entire program to load before testing the audio
5. Once the CD is fully loaded it is then stored in the digital flash memory within the unit. The record light will turn off.
6. It is possible that your music player has a speaker button. If so, turn the speaker button on and test to see if you hear the audio. If you do not have a speaker button, you can always call the number the hold content is hosted on and take a listen!
7. Feel free to contact us if you have any questions! 763-595-8000